
Express5800/120Rf-2(Xeon/3.20G(1))

N8100-932 ご利用にあたって

このたびは、Express5800/120Rf-2をお買い求めいただきまことにありがとうございます。

本書には、本製品に関する補足事項が記載されています。
なくさないよう大切に保管してください。

本製品に添付の EXPRESSBUILDER に格納されているユーザーズガイドやオンラインドキュメント及び各種ユーティリティのご利用にあたっては、型名の **N8100-893/921/922** を **N8100-932** と読み替えてご利用ください。

以下に N8100-893/921/922 と N8100-932 の差分を示します。CPU クロック以外の差分はありません。

型名	CPU
	クロック / キャッシュ
N8100-893	2.4BG / 512KB
N8100-921	2.8BG / 512KB
N8100-922	3.06G / 512KB
N8100-932	3.20G / 1MB

NEC Express5800/120Rf-2(XEON/2.8BG(512))

NEC Express5800/120Rf-2(Xeon/3.20G(1))

Notification for using N8100-921F/932F

Thank you very much for purchasing NEC Express5800/120Rf-2 lately.

The supplementary matter about this product is indicated by this book.
Keep this document for future reference.

Please read model name N8100-922F as N8100-921F/932F using the USERS GUIDE and the on-line document included in EXPRESSBUILDER, and various utilities.

The following is the difference of N8100-922F, and N8100-921F/932F.

There is no difference except a CPU clock.

N Code	CPU
	Clock / Cache
N8100-921F	2.8BG / 512KB
N8100-922F	3.06G / 512KB
N8100-932F	3.20G / 1MB

NEC

856-123000-004-0-1



*856-123000-004-00 *